

# TABLE OF CONTENTS

|   |                               |   |
|---|-------------------------------|---|
| 1 | <b>Before driving</b>         | Adjusting and operating features such as door locks, mirrors, and steering column                           |
| 2 | <b>When driving</b>           | Driving, stopping and safe-driving information  |
| 3 | <b>Interior features</b>      | Air conditioning and audio systems, as well as other interior features for a comfortable driving experience |
| 4 | <b>Maintenance and care</b>   | Cleaning and protecting your vehicle, performing do-it-yourself maintenance, and maintenance information    |
| 5 | <b>When trouble arises</b>    | What to do if the vehicle needs to be towed, gets a flat tire, or is involved in an accident                |
| 6 | <b>Vehicle specifications</b> | Detailed vehicle information  |
| 7 | <b>For owners</b>             | Reporting safety defects for U.S. owners and seat belt instructions for Canadian owners                     |
|   | <b>Index</b>                  | Alphabetical listing of information contained in this manual  |