

A

- A/C** 270
- ABS**..... 245
- Active head restraint**..... 78
- Air conditioning filter**..... 449
- Air conditioning system**
 - Air conditioning filter 449
 - Automatic air conditioning system..... 270
 - Remote air conditioning system..... 285
 - Steering wheel climate remote control switches 280
- Airbags**
 - Airbag operating conditions.. 117
 - Airbag precautions for your child..... 121
 - Airbag warning light..... 489
 - Curtain shield airbag precautions 121
 - Front passenger occupant classification system 126
 - General airbag precautions.. 121
 - Locations of airbags 113
 - Modification and disposal of airbags 125
 - Side airbag precautions..... 121
 - Side and curtain shield airbags operating conditions..... 117
 - SRS airbags 113
- Antenna**..... 298
- Anti-lock brake system**..... 245
- Armrest** 383
- Audio input** 322
- Audio system**
 - Antenna 298
 - Audio input 322
 - AUX adapter..... 322
 - CD player/changer 303
 - MP3/WMA disc..... 311
 - Optimal use 319
 - Portable music player..... 322
 - Radio 294
 - Steering switches 323

B

- Automatic headlight leveling system**206
- Automatic light control system**206
- AUX adapter**322
- Auxiliary boxes**375
- Back door**
 - Back door72
 - Smart key system.....43
 - Wireless remote control63
- Back-up lights**
 - Replacing light bulbs464
 - Wattage.....559
- Battery**
 - Checking428
 - Hybrid battery (traction battery).....32
 - If the vehicle 12 volt battery is discharged535
 - Preparing and checking before winter261
- Bluetooth®**363
- Bottle holder**.....374
- Brake**
 - Fluid424
 - Parking brake 179
- Brake assist**.....245
- Break-in tips** 151
- Brightness control**
 - Instrument light control 184

C

Care
 Exterior 396
 Interior 399
 Seat belts 400
Cargo capacity 255
Cargo hooks 385
CD player/changer 303
Chains 264
Child-protectors 68
Child restraint system
 Booster seats, definition 132
 Booster seats, installation 137
 Convertible seats,
 definition 132
 Convertible seats,
 installation 137
 Front passenger occupant
 classification system 126
 Infant seats, definition 132
 Infant seats, installation 137
 Installing child restraint
 system with
 LATCH system 138
 Installing child restraint
 system with seatbelts 140
 Installing child restraint
 system with top straps 144
Child safety
 Airbag precautions 121
 Child restraint system 132
 Child-protectors 68
 How your child should wear
 the seatbelt 88
 Installing child restraints 137
 Moon roof precautions 100
 Power window lock switch 98
 Power window precautions 99
 Removed electronic key
 battery precautions 453
 Seat belt precautions 89
 Back door 72

Cleaning
 Exterior 396
 Interior 399
 Seat belts 400
Clock 378
Condenser 424
Console box 369
Cooling system
 Hybrid system overheating ... 540
Cruise control
 Cruise control 214
 Dynamic radar
 cruise control 218
Cup holders 372
Curtain shield airbags 113
Customizable features 579

D

**Daytime running light
 system** 207
Defogger
 Rear window 289
 Side mirror 289
Dimension 548
Dinghy towing 267
Display
 Trip information 188
 Warning messages 500
Do-it-yourself maintenance 408
Door courtesy lights 363
Door lock
 Back door 72
 Side doors 67
 Smart key system 43
 Wireless remote control 63
Doors
 Back door 72
 Side doors 67
 Rear door child protector 67

Driver's seat belt reminder light 491

Driving

- Break-in tips 151
- Correct posture..... 111
- Procedures..... 150
- Winter driving tips..... 261

E **Electric Power Steering** 245

Electronic key

- Replacing battery 452
- When the electronic key battery is discharged..... 533

Emergency flashers 478

Emergency, in case of

- If a warning buzzer sounds 488
- If a warning light turns on 488
- If a warning message is displayed 500
- If the electronic key does not operate properly..... 533
- If the hybrid system will not start..... 530
- If the 12 volt battery is discharged 535
- If you have a flat tire 516
- If you lose your keys..... 532
- If you think something is wrong 485
- If your vehicle becomes stuck..... 545
- If your vehicle needs to be towed 479
- If your vehicle overheats 540

Engine

- Compartment417
- Hood.....412
- How to start the hybrid system162
- If the hybrid system will not start.....530
- Ignition switch..... 162
- Overheating.....540
- “POWER” switch 162

Engine oil

- Capacity552
- Checking418
- Preparing and checking before winter261

Engine/power control unit coolant

- Capacity554
- Checking422
- Preparing and checking before winter261

Engine oil maintenance data420

Enhanced VSC (Vehicle Stability Control).....245

EPS.....245

Event data recorder486

F **Floor mats**.....384

Fluid

- Brake.....424
- Washer.....426

Fog lights

- Replacing light bulbs464
- Switch.....209
- Wattage.....559

Front passenger occupant classification system126

Front passenger's seat belt reminder light.....491

Front seats

- Adjustment78

Front side marker lights	
Replacing light bulbs	464
Wattage	559
Front turn signal lights	
Replacing light bulbs	464
Wattage	559
Fuel	
Capacity	550
Fuel gauge	181
Information	560
Refueling	104
Type	560
Fuel door	104
Fuel filler door	104
Fuses	454
G	
Garage door opener	389
Gauges	181
Glove box	368
H	
Hands-free system	
(for cellular phone)	363
Hazard lights	
Switch	478
Head restraints	82
Headlight cleaner	213
Headlights	
Replacing light bulbs	464
Switch	206
Wattage	559
Heaters	
Seat heaters	381
Side mirror	289
Hood	412
Hooks	
Cargo	385
Horn	180

Hybrid system	
Emergency shut off system	33
Energy monitor/ consumption screen	190
High-voltage components	32
Power switch	162

I	
I/M test	407
Identification	
Engine	549
Vehicle	549
Ignition switch	162
Illuminated entry system	363
Immobilizer system	108
Indicator lights	185
Initialization	
Items to initialize	585
Inside rear view mirror	93
Instrument panel light	
control	184
Interior lights	
Interior lights	363
Switch	363
Wattage	559
J	
Jack	
Positioning a floor jack	415
Vehicle-equipped jack	516
Jack handle	516

K	Keyless entry	63
	Keys	
	Electronic key	63
	If you lose your keys.....	532
	If your electronic key	
	battery is discharged.....	533
	Key number plate	42
	Keyless entry.....	43
	Keys	41
	"POWER" switch	162
	Mechanical key.....	41
	Wireless remote control key ...	63
	Knee airbag	113
L	Lane keeping assist	235
	Language	
	Multi-information	
	display.....	188
	License plate lights	
	Replacing light bulbs	464
	Wattage.....	559
	Light bulbs	
	Replacing	464
	Wattage.....	559
	Lights	
	Emergency flasher switch	478
	Fog light switch.....	209
	Hazard light switch	478
	Headlights switch	206
	Interior lights.....	363
	Replacing light bulbs	464
	Turn signal lever.....	178
	Vanity lights.....	377
	Wattage.....	559
	LKA	235
	Load capacity	260
	Luggage compartment light	
	Switch.....	73
	Wattage.....	559
	Luggage cover	385

M	Maintenance	
	Do-it-yourself	
	maintenance	408
	General maintenance.....	404
	Maintenance data.....	548
	Maintenance	
	requirements.....	402
	Meter	
	Instrument panel light	
	control	184
	Meters	181
	Micro dust and	
	pollen filter	274
	Mirrors	
	Inside rear view mirror.....	93
	Side mirror heater	289
	Side mirrors.....	96
	Vanity mirrors.....	377
	Moon roof	100
	MP3 disc	311
	Multi-information display	188
N	Noise from under vehicle	22
O	Odometer	181
	Oil	
	Engine oil	418
	Opener	
	Back door.....	72
	Fuel filler door	104
	Hood.....	412
	Outside rear view mirrors	
	Adjusting and folding.....	96
	Outside temperature	
	display	311
	Overhead console	370
	Overheating, Hybrid	
	system	540

P	Parking brake	179
	Parking lights	
	Replacing light bulbs	464
	Switch.....	206
	Wattage.....	559
	PCS	249
	Personal lights	368
	Power outlet	379
	Power windows	98
	Pre-Collision System	249
R	Radiator	424
	Radio	294
	Rear turn signal lights	
	Replacing light bulbs	464
	Wattage.....	559
	Rear view monitor system	231
	Rear window defogger	289
	Rear window wiper	
	and washer	212
	Remote air conditioning	
	system	285
	Replacing	
	Electronic key battery.....	452
	Fuses	454
	Light bulbs.....	464
	Tires	516
	Reporting safety defects for	
	U.S. owners	588

S	Seat belts	
	Adjusting the seat belt.....	85
	Automatic Locking Retractor	
	(ALR)	87
	Child restraint system	
	installation.....	137
	Cleaning and maintaining	
	the seat belts	400
	Emergency Locking Retractor	
	(ELR)	87
	How to wear your seat belt	85
	How your child should wear	
	the seat belt.....	88
	Pregnant women,	
	proper seat belt use.....	87
	Reminder light.....	491
	Seat belt extenders	88
	Seat belt pretensioners	86
	Seat heaters	381
	Seating capacity	260
	Seats	
	Adjustment	78
	Adjustment precautions	80
	Child seats/child restraint	
	system installation	137
	Cleaning	399
	Head restraint	82
	Properly sitting in the seat.....	111
	Seat heaters.....	381
	Service reminder	
	indicators	185
	Shift lever	
	Transmission.....	168
	Side airbags	113
	Side marker lights	
	Replacing light bulbs.....	464
	Switch	206
	Wattage.....	559
	Side mirror	
	Adjusting and folding.....	96

Smart key system
 Antenna location..... 46, 58
 Entry function 43
 Starting the hybrid system.... 162

Solar ventilation system 282

Spare tire
 Inflation pressure..... 557
 Storage location 517

Spark plug..... 554

Specifications 548

Speedometer 181

Steering wheel
 Adjustment 92
 Audio switches 323

Storage compartment 285

Storage feature..... 285

Stuck
 If your vehicle becomes stuck..... 545

Sun visors..... 376

Switch
 Driving mode select switch 172
 Emergency flasher switch 478
 Fog light switch..... 209
 Ignition switch..... 162
 Light switches..... 206
 Power door lock switch..... 67
 "POWER" switch 162
 Power window switch 98
 Ventilation switch..... 282
 Window lock switch 98
 Wipers and washer switch.... 210

Tail lights
 Switch..... 206

Talk switch..... 329

Telephone switch 329

T

Theft deterrent system
 Immobilizer system 108

Theft prevention labels.....110

Tire inflation pressure557

Tire information
 Glossary571
 Size567
 Tire identification number.....566
 Uniform tire quality grading ...569

Tires
 Chains264
 Checking433
 Compact spare tire.....517
 If you have a flat tire516
 Inflation pressure.....557
 Information564
 Pressure warning system.....434
 Replacing516
 Rotating tires433
 Size557
 Snow tires264
 Spare tire.....517

Tonneau cover385

Tools516

Total load capacity.....260

Towing
 Dinghy towing.....267
 Emergency towing.....479
 Trailer towing.....266

TRAC245

Traction control.....245

Trailer towing267

Transmission
 "P" position switch 174
 Transmission..... 168

Trip information34

Trip meter188

Turn signal lights
 Replacing light bulbs464
 Switch.....178
 Wattage559

V

Vanity lights
 Vanity lights377
 Wattage559
Vanity mirrors.....377
Vehicle identification
 number549
Vehicle load limits.....260

W

Warning buzzers
 Brake system488
 Open door491
 Seat belt reminder.....491
Warning lights
 Anti-lock brake
 system (ABS).....489
 Automatic headlight
 leveling system489
 Brake system488
 Charging system489
 Electric power steering489
 High coolant temperature.....491
 Low fuel level491
 Malfunction indicator lamp489
 Master warning.....491
 Open door491
 Pre-Collision system489
 Seat belt reminder.....491
 SRS airbags489
 Tire pressure491
Warning messages500
Washer
 Checking426
 Preparing and checking
 before winter261
 Switch.....210
Washing and waxing396

Weight

Cargo capacity255
 Load limits260
 Weight.....548
Wheels447
Window glasses98
Window lock switch.....98
Windows
 Power windows98
 Rear window defogger289
 Washer.....210
Windshield wipers210
Winter driving tips261
Wireless remote control key
 Locking/Unlocking.....63
 Replacing the battery452
WMA disc.....311

